



NOTES:

1. MEMBRANE ENDLAPS MUST BE 6" MINIMUM & FULLY ADHERED AT ALL MEMBRANE IN ALL LOCATIONS WHERE "FAST LAP" IS NOT PRESENT.

DRIP EDGE DETAIL

NUMBER: PG001

DATE: 05.17.01

REVISION:

BY: JEA



Polyglass USA Inc.

Corporate Office and Manufacturing Facility: 150 Lyon Drive, Fernley, Nevada 89408
 Phone (775) 575-6007 - Fax (775) 575-2314 - Toll Free (800) 222-9782
 Manufacturing Facilities: 555 Oakridge Road, Humboldt Industrial Park, Hazleton, Pennsylvania 18201
 Tel. (570) 384-1230 - Fax (570) 384-3282 - Toll Free (800) 894-4563
 621 Snively Avenue, Winterhaven, Florida 33880
 Phone: 863-297-5800 - Fax: 863-297-5858 - Toll Free: 866-802-8017
 e-mail: technical@polyglass.com • www.polyglass.com